

# SMS ALERT 9+ AND ROBOGUARD HQ WIRING

WHEN THE SMS ALERT IS ARMED, WAIT 20S BEFORE ACTIVATING A BEAM

